

ISUZU 6WG1 XYSS01 (Tier III)

LINE AÇIKLAMA	PARÇA NO
1 KIT GASKET KOMP	1-87812966-1
2 KIT GASKET UPPER	1-87812967-1
3 COVER SEAL	1-11173119-1
4 CAP	8-94399723-0
5 CLINDER HEAD GASKET	1-11141265-3
6 CYLINDER HEAD	1-11110939-2
7 VALVE GUIDE	1-11721012-0
8 GLOW PLUG	1-82513044-3
9 VALVE SEAT IN	1-11715109-0
10 VALVE SEAT EX	1-11711074-0
11 LINER SET	1-87812859-0
12 LINER	1-11261379-2
13 SEAL	1-11367130-0
14 VALVE INTAKE	1-12551162-1
15 VALVE EKHAUST	1-12552100-2
16 GUIDE SEAL VAL.	1-12569020-0
17 SEAT SPRING ALT	1-12563056-2
18 SEAT SPRING ÜST	1-12563060-0
19 SPRING INLET	8-97603305-0
20 SPRING EXHAUST	1-12561093-0
21 VALVE TAB	1-12565007-0
22 CAMSHAFT	1-12511255-2
27 PISTON	1-12112001-0
28 RING SET	1-12121154-0
29 CONROD BEARING	1-12271096-0
30 CONROD BUSHING	1-12251037-4
31 MAIN BEARING	1-11510093-3
32 TRUST WASHER	1-11599009-0
33 TRUST WASHER	1-11599009-0
34 FLYWHEEL GEAR	1-12333013-1
35 CRANKSHAFT FRONT SEAL	1-09625556-2
36 CRANKSHAFT REAR SEAL	1-09625557-1
37 VALVE SEAL	8-97607-598-1
38 VALVE SEAL	1141150941
39 VALVE SEAL	1-14145182-1
40 TURBOCHARGER SEAL	8-98018855-0
41 TURBOCHATGER SEAL	1-14145175-0
42 PUMP WATER	8-98019741-0
43 REPAIR KIT	1-87811843-0
44 TERMOSTAT A	1-13770089-1
46 FAN	1-13660331-1
47 VBELT	1-13671520-0
48 TURBOCARGER	1-14400437-0
49 OIL PUMP	1-13100312-0
50 STARTER	1-81100341-3
51 ALTERNATÖR	1-81200530-3
52 SENSOR	8-12146830-0
53 SENSOR	8-97217778-0
54 SENSOR	8-97363936-0
55 DIPSTICK	1-11760446-1

FULE SYSTEM

1 INJECTOR ASSY.	1-15300436-0
2 COMMON RAIL	8-97603121-1
3 FUEL PUMP	8-97603414-0
4 FEED PUMP	
5 PUMP OVERHAUL KIT	
6 LIMITER	8-97318691-0
7 PIPE INJ NO :1	1-15416842-1
8 PIPE INJ NO :2	1-15416843-2
9 PIPE INJ NO :3	1-15416844-1
10 PIPE INJ NO :4	1-15416845-1
11 PIPE INJ NO :5	1-15416846-2
12 PIPE INJ NO :6	1-15416847-1

ISUZU 6HK1 XYSS01(T III)

LINE	PARTS NAME	NOT	PARTS NO
1	KIT GASKET KOMP		1-8781298-20
2	KIT GASKET UPPER		1-87812985-0
3	COVER SEAL		8-94391379-0
4	COVER		8-94399723-0
5	CLINDER HEAD GASKET		8-97601819-4
6	CYLINDER HEAD		8-97606996-3
7	VALVE GUIDE		8-94390780-0
8	GLOW PLUG		8-94390777-5
9	VALVE SEAT IN		8-94395888-0
10	VALVE SEAT EX		8-97216511-0
11	LINER SET		1-87812986-0
12	LINER		8-94391602-0
13	COVER SEAL		1-11367131-0
14	VALVE INLET		8-94395882-0
15	VALVE EKHAUST		8-97209876-2
16	GUIDE SEAL VAL.		8-97120307-0
17	SEAT SPRING ALT		8-94391468-0
18	SEAT SPRING ÜST		8-94390783-2
19	SPRING INLET		8-97352888-0
20	SPRING EXHAUST		8-94395885-1
21	VALVE TAB		5-12565004-0
22	CAMSHAFT		8-97601438-0
23	CAMSHAFT BUSHING		8-97356939-0
24	CAMSHAFT BUSHING		8-97602699-0
25	PUSH ROD		N/A
26	TAPPET		N/A
27	PISTON		8-98023526-1
28	RING SET		8-98017166-0
29	CONROD BEARING		8-94395757-1
30	CONROD BUSHING		8-9439461-30
31	MAIN BEARING		8-97372076-0
32	TRUST WASHER		8-94399-277-0
33	TRUST WASHER		8-94399283-0
34	FLYWHEEL GEAR		8-94391953-0
35	SEAL		8-97602378-0
36	SEAL		8-97209342-2
37	VALVE SEAL		8-94390775-0
38	VALVE SEAL		8-97601777-0
39	VALVE SEAL		8-94393672-2
40	TURBOCHARGER SEAL		8-98018855-0
41	TURBOCHARGER SEAL		N/A
42	PUMP WATER		1-13650133-2
43	REPAIR KIT		1-87812075-1
44	TERMOSTAT A		8-97602048-1
45	TERMOSTAT B		8-97602393-0
46	FAN		1-13660332-1
47	VBELT		1-13671516-0
48	TURBOCHARGER		1-14400442-0
49	OIL PUMP		8-94390414-1
50	STARTER		1-81100414-2
51	ALTERNATÖR		1-81200603-2
52	SENSOR		8-97170327-0

53	SENSOR	N/A
54	SWITCH	8-97125601-1
55	DIPSTICK	1-11760455-0

FUEL SYSTEM

1	INJECTOR ASSY.	8-97329703-2
2	COMMON RAIL	8-97323019-0
3	FUEL PUMP	1-15603508-1
4	FEED PUMP	8-98009397-0
5	PUMP OVERHAUL KIT	N/A
6	LIMITER	8-97381346-0
7	PIPE INJ NO :1	8-97602674-2
8	PIPE INJ NO :2	8-97602675-2
9	PIPE INJ NO :3	8-97601771-2
10	PIPE INJ NO :4	8-97600996-3
11	PIPE INJ NO :5	8-97600997-2
12	PIPE INJ NO :6	8-97600998-2

ISUZU 6UZ1 XYSS01

LINE	PARTS NAME	NOT	PARTS NO
1	KIT GASKET KOMP		1-87813071-0
2	KIT GASKET UPPER		1-87813073-0
3	COVER SEAL		1-11173118-0
4	COVER		8-94399723-0
5	CLINDER HEAD GASKET		1-11141292-1
6	CYLINDER HEAD		8-98050442-0
7	GUIDE VALVE		8-97376719-1
8	GLOW PLUG		8-94390777-5
9	SEAT VALVE IN		1-11715124-0
10	SEAT VALVE EX		1-11711087-0
11	LINER SET		1-87813009-0
12	LINER		1-11261369-0
13	COVER SEAL		1-11367129-1
14	VALVE INLET		8-97388643-1
15	VALVE EXHAUST		8-97388644-0
16	SEAL GUIDE		8-97376720-0
17	SEAT SPRING ALT		8-94391468-0
18	SEAT SPRING ÜST		8-94390783-2
19	SPRING INLET		8-97603260-0
20	SPRING EXHAUST		8-97603261-0
21	VALVE TAB		5-12565004-0
22	CAMSHAFT		8-97603050-0
27	PISTON		8-98028737-0
28	RING SET		8-97611077-0
29	CONROD BEARING		8-97605484-0
30	CONROD BUSHING		1-12251051-0
31	MAIN BEARING		8-97609768-0
32	TRUSTWASHER		1-1159900-50
33	TRUST WASHER		1-11599005-0
34	FLYWHEEL GEAR		1-12333013-1
35	FRONT SEAL		1-09625540-3
36	REAR SEAL		1-09625541-2
37	VALVE SEAL		8-97603676-0
38	VALVE SEAL		1-09623431-0
39	VALVE SEAL		1-14145205-0
40	TURBOCHARGER SEAL		1-14145208-1
41	ADAPTOR SEAL		1-14145121-0
42	PUMP WATER		8-98047690-0
43	KIT REP W/P		1-87813076-0
44	TERMOSTAT A	82 C	1-13770089-1
45	TERMOSTAT B		
46	FAN		1-13660331-1
47	VBELT		1-13671473-0
48	TURBOCHARGER		8-98002560-0
49	OIL PUMP		8-97607586-0
50	STARTER		1-81100432-2
51	ALTERNATÖR		1-81200603-2
52	SENSOR		8-12146830-0

53	SENSOR	8-97217778-0
54	SWITCH	8-97363963-0

FUEL SYSTEM

1	INJECTOR ASSY.	8-97603415-2
2	COMMON RAIL	8-97603-121-1
3	PUMP ASSY	8-98013-910-0
4	FEED PUMP	NA
5	PUMP OVERHAUL KIT	NA
6	LIMITER	8-97318691-0
7	PIPE INJ NO:1	8-97605246-0
8	PIPE INJ NO:2	8-97605247-0
9	PIPE INJ NO:3	8-97605248-0
10	PIPE INJ NO:4	8-97603742-0
11	PIPE INJ NO:5	8-97605945-0
12	PIPE INJ NO:6	8-97603744-0

ISUZU 4HK1 XYSS02

LINE	PARTS NAME	NOT	PARTS NO
1	KIT GASKET KOMP		5-87814932-2
2	KIT GASKET UPPER		5-87815011-0
3	COVER SEAL		8-97331359-1
4	CAP		8-94399723-0
5	CLINDER HEAD GASKET		8-97375433-0
6	CYLINDER HEAD		8-98008363-3
7	GUIDE VALVE		8-94390780-0
8	GLOW PLUG		8-94390777-5
9	SEAT VALVE IN		8-94395888-0
10	SEAT VALVE EX		8-97216511-0
11	LINER SET		5-87814862-1
12	LINER		8-94391602-0
13	KARTER CONTASI		8-97363845-1
14	VALVE INLET		8-94395882-0
15	VALVE EXHAUST		8-97209876-2
16	SEAL GUIDE		8-97120307-0
17	SEAT SPRING ALT		8-94391468-0
18	SEAT SPRING ÜST		8-94390783-2
19	SPRING INLET		8-94395884-0
20	SPRING EXHAUST		8-94395885-1
21	VALVE TAB		5-12565004-0
22	CAMSHAFT		8-97262166-0
23	CAMSHAFT UPPER		8-97356939-0
24	CAMSHAFTLOWER		8-97356939-0
27	PISTON		8-98023526-1
28	RING SET		8-98017166-0
29	CONROD BEARING		8-94395757-1
30	CONROD BUSHING		8-94394613-0
31	MAIN BEARING		8-97372076-0
32	TRUST WASHER		8-94399277-0
33	TRUST WASHER		8-94399283-0
34	FLYWHEEL GEAR		8-94393132-0
35	FRONT SEAL		8-97382955-0
36	REAR SEAL		8-97209342-3
37	VALVE SEAL		N/A
38	VALVE SEAL		8-97363644-0
39	VALVE SEAL		8-97146499-0
40	TURBOCHARGER SEAL		1-14145184-0
41	ADAPTOR SEAL		N/A
42	PUMP WATER		8-98038845-0
43	KIT REP W/P		N/A
44	TERMOSTAT A	82 C	8-97300790-1
45	TERMOSTAT B	85 C	8-97300787-2
46	FAN		1-13660328-0
47	VBELT		8-98042862-0
48	TURBOCHARGER		8-98030217-0
49	OIL PUMP		1-13100313-1
50	STARTER		8-98054063-0
51	ALTERNATÖR		8-97375017-1
52	SENSOR		8-12146830-0
53	SENSOR		8-98027456-0
54	SWITCH		8-97125601-1

FUEL SYSTEM

1	INJECTOR ASSY.		8-97329703-2
2	COMMON RAIL		8-97306063-2
3	PUMP ASSY		8-97306044-8
4	FEED PUMP		8-98009397-0
5	PUMP OVERHAUL KIT		8-98043687-0
6	LIMITER		8-97318691-0
7	PIPE INJ NO:1		8-9737183-10
8	PIPE INJ NO:2		8-97373417-0
9	PIPE INJ NO:3		8-97371833-0
10	PIPE INJ NO:4		8-97371834-0
11			
12			

ISUZU 6SD1 QXB

LINE	PARTS NAME	NOT	PARTS NO
1	KIT GASKET KOMP		1-87812148-1
2	KIT GASKET UPPER		1-87811193-1
3	COVER GASKET		1-11173085-0
4	CAP		1-11750020-0
5	CLINDER HEAD GASKET		1-11141216-4
6	CYLINDER HEAD		1-11110846-3
7	VALVE GUIDE		1-11721008-0
8	GLOW PLUG		1-82513044-2
9	VALVE SEAT IN		1-11715122-0
10	VALVE SEAT EX		1-11711041-0
11	LINER SET		1-87812149-0
12	LINER		1-11261299-0
13	COVER SEAL		1-11367129-1
14	VALVE INLET		1-12551161-2
15	VALVE EKHAUST		1-12552108-2
16	GUIDE SEAL VAL.		1-12569019-1
17	SEAT SPRING ALT		9-12563231-0
18	SEAT SPRING ÜST		1-12563059-1
19	SPRING INLET		1-12561051-0
20	SPRING EXHAUST		1-12561072-0
21	VALVE TAB		1-12565002-0
22	CAMSHAFT		1-12511249-1
27	PISTON		1-12111974-0
28	RING SET		1-12121137-1
29	CONROD BEARING		1-12271084-0
30	CONROD BUSHING		1-12251021-1
31	MAIN BEARING		1-11510087-0
32	TRUST WASHER		1-11599007-0
34	FLYWHEEL GEAR		1-12333016-0
35	FRONT SEAL		1-09625540-3
36	REAR SEAL		1-09625541-2
37	VALVE SEAL		N/A
38	ADAPTOR SEAL		1-09623330-0
39	VALVE SEAL		1-14145144-0
40	TURBOCHARGER SEAL		1-14145140-0
41	ADAPTOR SEAL		N/A
42	PUMP WATER		1-13650068-1
43	REAPIR KIT WATER PUMP		1-87812151-0
44	TERMOSTAT A		1-13770069-0
45	TERMOSTAT B		N/A
46	FAN		1-13660332-1
47	VBELT		1-13671516-0
48	TURBOCHARGER		1-14400388-0
49	OIL PUMP		1-13100191-2
50	STARTER		1-81100422-0
51	ALTERNATÖR		1-81200603-2
52	SENSOR		8-97217444-1
53	SENSOR		1-82410170-0
54	SWITCH		8-97125601-1
55	DIPSTICK		1-11760417-0

FUEL SYSTEM

1	FEED PUMP	1-15750194-0
2	LIMITER	1-15631230-0
3	ELEMAN	1-15632065-0
4	VALVE	1-15641035-0
5	RING	1-15643015-0
6	ELEMAN ORIFICI	1-15639084-0
7	HOLDER	1-15644011-0
8	INJECTOR ASS	1-15300393-2
9	NOZZLE	1-15319028-0
10	FUEL PUMP	1-15603483-0

ISUZU 6HK1 XQB

LINE	PARTS NAME	NOT	PARTS NO	QNT
1	KIT GASKET KOMP		1-87812316-0	
2	KIT GASKET UPPER		1-87812070-2	
3	COVER SEAL		8-94391379-0	
4	CAP		8-94399723-0	
5	CLINDER HEAD GASKET		8-94392721-3	
6	CYLINDER HEAD		8-97602687-1	
7	VALVE GUIDE		8-94390780-0	
8	GLOW PLUG		8-94390777-5	
9	VALVE SEAT IN		8-94395888-0	
10	VALVE SEAT EX		8-97216511-0	
11	LINER SET		1-87812775-1	
12	LINER		8-94391602-0	
13	COVER		1-11367131-0	
14	VALVE INLET		8-94395882-0	
15	VALVE EXHAUST		8-97209876-2	
16	GUIDE SEAL VALVE		8-97120307-0	
17	SEAT SPRING LOWER		8-94391468-0	
18	SEAT SPRING UPPER		8-94390783-2	
19	SPRING INLET		8-94395884-0	
20	SPRING EXHAUST		8-94395885-1	
21	VALVE TAB		5-12565004-0	
22	CAMSHAFT		8-94390469-1	
23	CAMSHAFT BUSHING UPPER		8-97356939-0	
24	CAMSHAFT BUSHING LOWER		8-97602699-0	
27	PISTON		1-12111976-0	
28	RING SET		8-94391502-3	
29	CONROD BEARING		8-94395757-1	
30	CONROD BUSHING		8-94394613-0	
31	MAIN BEARING		8-94391514-0	
32	TRUST WASHER		8-94399277-0	
33	TRUST WASHER		8-94399283-0	
34	FLYWHEEL GEAR		8-94391953-0	
35	FRONT SEAL		8-97602378-0	
36	REAR SEAL		8-97602379-0	
37	VALVE SEAL		8-94390775-0	
38	VALVE SEAL		8-94394141-0	
39	VALVE SEAL		8-94393672-2	
40	TURBO SEAL		8-94390044-0	
41	ADAPTOR SEAL		N/A	
42	PUMP WATER		1-13650133-2	
43	RAPAIR KIT WATER PUMP		1-87812075-0	
44	TERMOSTAT A		8-94397310-0	
45	TERMOSTAT B		8-94392817-0	
46	FAN		1-13660332-1	
47	VBELT		1-13671516-0	
48	TURBOCHARGER		1-14400405-0	
49	OIL PUMP		1-13100313-1	
50	STARTER		1-81100414-2	
51	ALTERNATÖR		1-81200633-0	
52	SENSOR		8-97217444-1	
53	SENSOR		N/A	
54	SWITCH		N/A	
55	DIPSTICK		1-11760421-0	
FUEL SYSTEM				
1	FEED PUMP		1-15750-130-0	
2	LIMITER		1-15631225-0	
3	ELEMAN		1-15632061-0	
4	VALVE		1-15641035-0	
5	RING		1-15643015-0	
6	ELEMAN ORIFICI		1-15639084-0	
7	HOLDER		1-15644011-0	
8	INJECTOR ASS		1-15300389-1	
9	NOZZLE		1-15319026-0	
10	FUEL PUMP		1-15603484-0	

ISUZU 6BG1

LINE	PARTS NAME	NOT	PARTS NO
1	KIT GASKET KOMP		1-87812311-2
2	KIT GASKET UPPER		1-87812271-2
3	COVER GASKET		1-11173059-0
4	CAP		9-11751038-1
5	CLINDER HEAD GASKET		1-11141196-1
6	CYLINDER HEAD		1-11110938-0
7	VALVE GUIDE		1-11721013-0
8	GLOW PLUG		1-82513045-1
9	VALVE SEAT IN		5-11711028-0
10	VALVE SEAT EX		8-97037686-0
11	LINER SET		1-87812791-1
12	LINER		1-11261383-0
13	COVER SEAL		1-11367132-0
14	VALVE INLET		1-12551165-0
15	VALVE EXHAUST		1-12552111-0
16	GUIDE SEAL VAL.		8-97120167-0
17	SEAT SPRING ALT		5-12563001-0
18	SEAT SPRING ÚST		8-94145579-0
19	SPRING INLET		1-12561099-1
20	SPRING EXHAUST		1-12561099-1
21	VALVE TAB		5-12565006-0
22	CAMSHAFT		1-12514005-0
23	CAMSHAFT BUSHING		9-11693035-0
24	CAMSHAFT BUSHING		9-11691048-0
25	PUSH ROD		1-12575036-0
26	TAPPET		5-12571003-3
27	PISTON		8-97358574-0
28	RING SET		1-12121146-0
29	CONROD BEARING		9-12271608-0
30	CONROD BUSHING		1-12251032-0
31	MAIN BEARING		1-11510074-1
32	TRUST WASHER		1-11680001-1
33	TRUST WASHER		1-11680001-3
34	FLYWHEEL GEAR		8-94393132-0
35	FRONT SEAL		1-09625438-0
36	REAR SEAL		8-97072823-1
37	VALVE SEAL		8-97235788-1
38	VALVE SEAL		N/A
39	VALVE SEAL		8-94404610-0
40	TURBO SEAL		1-14145140-0
41	TURBO SEAL		N/A
42	PUMP WATER		8-97253028-1
43	WATER PUMP KIT		5-87814320-0
44	TERMOSTAT A		1-13770070-0
45	TERMOSTAT B		N/A
46	FAN		1-13660328-0
47	VBELT		1-13671499-0
48	TURBOCHARGER		1-14400377-0
49	OIL PUMP		1-13100277-0
50	STARTER		1-81100401-3
51	ALTERNATOR		1-81200590-3
52	SENSOR		8-97217444-0
53	SENSOR		1-82410142-0
54	SWITCH		8-97125601-1
55	DIPSTICK		1-11760420-1

FUEL SYSTEM

1	FEED PUMP		1-15750197-0
2	LIMITER		
3	ELEMAN		1-15632058-0
4	VALVE		1-15641031-0
5	RING		
6	ELEMAN ORIFICI		1-15649005-0
7	HOLDER		1-15644009-0
8	INJECTOR ASS		1-15300421-0
9	NOZZLE		1-15311316-0
10	FUEL PUMP		1-15603427-1

ISUZU 4BG1

LINE	PARTS NAME	NOT	PARTS NO
1	KIT GASKET KOMP		5-87814002-4
2	KIT GASKET UPPER		5-87814003-0
3	COVER GASKET		5-11173016-0
4	CAP		8-94399723-0
5	CLINDER HEAD GASKET		8-97222117-1
6	CYLINDER HEAD		8-97222109-0
7	VALVE GUIDE		1-11721013-0
8	GLOW PLUG		1-82513044-0
9	VALVE SEAT IN		5-11711028-0
10	VALVE SEAT EX		8-97037686-0
11	LINER SET		5-87814459-1
12	LINER		1-11261383-0
13	COWER SEAL		8-97352403-0
14	VALVE INLET		1-12551165-0
15	VALVE EXHAUST		1-12552111-0
16	GUIDE SEAL VAL.		8-97120167-0
17	SEAT SPRING ALT		5-12563001-0
18	SEAT SPRING ÜST		8-94145579-0
19	SPRING INLET		1-12561099-0
20	SPRING EXHAUST		1-12561099-0
21	SUBAP TIRNAĞI		5-12565006-0
22	CAMSHAFT		8-94409412-0
23	CAMSHAFT BUSHING		9-11613035-0
24	CAMSHAFT BUSHING		9-11611048-0
25	PUSH ROD		1-12575036-0
26	TAPPET		5-12571003-2
27	PISTON		8-97358574-0
28	RING SET		1-12121146-0
29	CONROD BEARING		9-12271608-0
30	CONROD BUSHING		1-12251032-0
31	MAIN BEARING		8-97071661-0
32	TRUST WASHER		8-97071358-0
33	TRUST WASHER		8-97071358-0
34	FLYWHEEL GEAR		8-97175902-0
35	FRONT SEAL		1-09625438-0
36	REAR SEAL		8-97072823-1
37	VALVE SEAL		8-97235788-1
38	VALVE SEAL		8-94370676-0
39	VALVE SEAL		8-94404610-0
40	TURBO SEAL		8-94369023-0
41	ADAPTOR SEAL		N/A
42	PUMP WATER		8-97253028-1
43	WATER PUMP KIT		8-97253030-0
44	TERMOSTAT A		1-13770-070-0
45	TERMOSTAT B		N/A
46	FAN		8-97161600-0
47	VBELT		8-97232252-0
48	TURBOCHARGER		8-97223428-0
49	OIL PUMP		8-97065384-0

50	STARTER	8-97225199-1
51	ALTERNATOR	1-81200530-3
52	SENSOR	8-97217444-0
53	SENSOR	N/A
54	SWITCH	8-97125601-1
55	DIPSTICK	8-97020985-0

YAKIT SİSTEMİ

1	FEED PUMP	8-97357265-0
2	LIMITER	
3	ELEMAN	1-15631069-0
4	VALVE	8-97123605-0
5	RING	5-15643001-0
6	ELEMAN ORIFICI	5-15629045-0
7	HOLDER	5-15644017-0
8	INJECTOR ASS	8-97222170-0
9	NOZZLE	1-15311301-0
10	FUEL PUMP	

